inverting signals
from Schmitt
triggers on board

rtm_detector

rtmm_i   rtmm_ok_o

rtmp_i   rtmp_ok_o

set ERR LED