

We use buck circuits
to convert the PWM
uC output to DC

A 18V zener is used
to keep the gate bias
of the MOSFET low,
limiting V_{th} shift due
to oxide traps

place close to
the MOSFETs

