

# Absolute encoder package

Fabien Le Mentec  
lementec@esrf.fr

version: SVN revision 550:552M

# Contents

<b>1 Description</b>	<b>3</b>
1.1 Overview . . . . .	3
1.2 Features and limitations . . . . .	4
1.3 Tested hardware . . . . .	4
1.4 Performances . . . . .	5
<b>2 Interfaces</b>	<b>6</b>
2.1 absenc_pkg.master . . . . .	6
2.2 absenc_pkg.slave . . . . .	6
<b>3 Examples</b>	<b>8</b>
3.1 master . . . . .	8
3.2 slave . . . . .	8


# 1 Description

## 1.1 Overview


The absenc\_pkg implements components for absolute encoder masters and slaves.

The term *master* refers to the component driving the clock, or at least initiating the data transfer. It is often referred to as the *controller*. The term *slave* refers to the actual encoder device.

This package is optimized for applications that can be dynamically configured to use one amongst different types of interfaces at a particular time. As much as possible, resources that can be shared across interfaces are factorized (counters, comparators, shift registers ...) and accessed through a multiplexer. However, and in order to avoid penalizing simpler applications, static configuration allows to exclude resources associated with an unused interface.



The master implements the following data conversion pipeline:



## 1.2 Features and limitations

- Applicable to all
  - master and slave modes,
  - configurable master clock frequency,
  - configurable data length (up to 48 bits),
  - static timeout.
- ENDAT
  - send position mode version 2.1 only,
  - no CRC check.
- BISS
  - point to point configuration only,
  - no interleaved bit support (ie. CDS, CDM).
- SSI
  - optional gray data coding (master only),
  - optional parity bit (not checked).

## 1.3 Tested hardware

The package has been tested with the following masters:

- ICEPAP ESRF motor controller (SSI),
- PEPU ESRF encoder processor (SSI, BISS, ENDAT),
- MUSST ESRF sequencing platform (SSI),
- Aerotech Soloist CP controller (BISS, ENDAT).

The package has been tested with the following slaves:

- PEPU ESRF encoder processor (SSI, BISS, ENDAT),
- Kubler sendix 5863 SIL BISS encoders,
- IVO industries GA241 SSI encoders,
- Heidenhain ROQ 425 512 ENDAT encoders,
- Heidenhain ROQ 437 2048 ENDAT encoders.

## 1.4 Performances

**TODO:**

## 2 Interfaces

### 2.1 absenc\_pkg.master

Interface from file ./../src/absenc\_pkg.vhd at line 390

```
component master
generic
(
    -- local clock frequency
    CLK_FREQ: integer;

    -- enable a specific implementation, or all by default
    -- disabling unneeded implementations optimizes resources
    ENABLE_ENDAT: boolean := TRUE;
    ENABLE_BISS: boolean := TRUE;
    ENABLE_SSI: boolean := TRUE
);
port
(
    -- local clock and reset
    clk: in std_logic;
    rst: in std_logic;

    -- ma_clk is the clock signal generated by the master
    -- to the slave. its frequency is CLK_FREQ / ma_fdiv
    ma_fdiv: in unsigned;
    ma_clk: out std_logic;

    -- master out, slave in
    mosi: out std_logic;
    miso: in std_logic;

    -- gate to drive output (1 to drive it). used in PEPU
    -- first versions, set to open if not used.
    gate: out std_logic;

    -- data received from slave. typically the position
    -- important: use the smallest possible width, as
    -- this is used to derive other resource sizes
    data: out std_logic_vector;

    -- data length. typically the encoder resolution
    -- important: use the smallest possible width, as
    -- this is used to derive other resource sizes
    len: in unsigned;

    -- the selected encoder type
    enc_type: in integer;

    -- ssi specific flags
    -- set to work.absenc_pkg.SSI_DEFAULT_FLAGS if unused
    -- ssi_flags<0>: ssi spy mode (ie. master without clock)
    -- ssi_flags<1>: 0 or 1 for binary or gray data coding
    -- ssi_flags<2>: '.S' terminating pattern
    -- ssi_flags<3>: 'ES' terminating pattern
    -- ssi_flags<4>: 'OS' terminating pattern
    ssi_flags: in std_logic_vector;

    -- ssi frame delay. divides CLK_FREQ
    -- set to work.absenc_pkg.SSI_DEFAULT_DELAY_FDIV if unused
    ssi_delay_fdiv: in unsigned
);
end component;
```

### 2.2 absenc\_pkg.slave

Interface from file ./../src/absenc\_pkg.vhd at line 183

```

component slave
generic
(
  -- local clock frequency
  CLK_FREQ: integer;

  -- enable a specific implementation, or all by default
  -- disabling unneeded implementations optimizes resources
  ENABLE_ENDAT: boolean := TRUE;
  ENABLE_BISS: boolean := TRUE;
  ENABLE_SSI: boolean := TRUE
);
port
(
  -- local clock and reset
  clk: in std_logic;
  rst: in std_logic;

  -- clock from master
  ma_clk: in std_logic;

  -- master in, slave out
  miso: out std_logic;
  mosi: in std_logic;

  -- gate to drive output (1 to drive it). used in PEPU
  -- first versions, set to open if not used.
  gate: out std_logic;

  -- data sent to master. typically the position
  -- important: use the smallest possible width, as
  -- this is used to derive other resource sizes
  data: in std_logic_vector;

  -- data length, typically the encoder resolution
  -- important: use the smallest possible width, as
  -- this is used to derive other resource sizes
  len: in unsigned;

  -- the selected encoder type
  enc_type: in integer;

  -- ssi specific flags
  -- set to work.absence_pkg.SSI_DEFAULT_FLAGS if unused
  -- ssi_flags <0>; unused
  -- ssi_flags <1>; 0 or 1 for binary or gray data coding
  -- ssi_flags <2>; 'S' terminating pattern
  -- ssi_flags <3>; 'ES' terminating pattern
  -- ssi_flags <4>; 'OS' terminating pattern
  ssi_flags: in std_logic_vector
);
end component;

```

## 3 Examples

### 3.1 master

Example from file ./../sim/common/main.vhd at line 228

```
master: work.absenc_pkg.master
generic map
(
  CLK_FREQ => CLK_FREQ
)
port map
(
  clk => clk,
  rst => rst,
  ma_fdiv => ma_fdiv,
  ma_clk => ma_clk,
  mosi => mosi,
  miso => miso,
  gate => open,
  data => master_data,
  len => len,
  enc_type => enc_type,
  ssi_flags => work.absenc_pkg.SSLDEFAULT.FLAGS,
  ssi_delay_fdiv => work.absenc_pkg.SSLDEFAULT.DELAY_FDIV
);
```

### 3.2 slave

Example from file ./../sim/common/main.vhd at line 208

```
slave: work.absenc_pkg.slave
generic map
(
  CLK_FREQ => CLK_FREQ
)
port map
(
  clk => clk,
  rst => rst,
  ma_clk => ma_delayed_clk,
  miso => miso,
  mosi => mosi,
  gate => open,
  data => slave_data,
  len => len,
  enc_type => enc_type,
  ssi_flags => work.absenc_pkg.SSLDEFAULT.FLAGS
);
```